

# Abbreviated Dial(Common) - Programming through Phone

Wednesday, September 22, 2010

9:39 PM

→ Can be programmed from any phone.

1. Press *arrow down* button on display.
2. Press *Prog* button on display.
3. Press *arrow down* button on display.
4. Press *Abb* on display for the UX5000. On the SV8100 press *SPD*
5. Enter 3 digit code. (000-999)
6. Enter telephone number and press *Hold* button.
7. Enter name on keypad up to 12 digits long. If you have 2 characters on the same button, press *#* to jump to the next space.
8. Press *Hold* button when finished.
9. Enter the next 3 digit code or hang up.