

Mailbox Notification

Saturday, October 30, 2010
10:22 PM

Setting Notification for the NEC Intramail

1. While the phone is idle and the handset is in the cradle, press VMsg
2. To go to the options menu dial 0 or press More> soft key
3. From the main menu of features dial 67 or press More> soft key
4. From the mailbox options menu dial 6 or press Notfy soft key
5. To change telephone and pager notification dial 7 or press Phone soft key
 - a. If notification is turned off press 6 or On soft key, if notification is on you can turn it off by dialing 6 or press the Off soft key.
 - b. Enter the two digit hour you want notification to start followed by either AM (2) or PM (7)
 - c. Enter the two digit hour you want the notification to end following by either AM (2) or PM (7)
 - d. For a number (cell phone or other telephone number) dial 6 or press Num soft key
 - e. For a digit pager press 3 or press Pager soft key
 - f. Dial the telephone number followed by #
6. To change E-mail notification press 3 or Email soft key
 - a. To turn e-mail notification on dial 6 or press On soft key